



**STIHL**





**iMOW® 3**  
**iMOW® 3 EVO**  
**iMOW® 4**  
**iMOW® 4 EVO**








# 1













## iMOW®










iMOW® 4  
iMOW® 4 EVO  
iMOW® 3\*, iMOW® 3 EVO\* \*CH, GB, AUS, NZ




## Install Kit










1





2





3




4




# 3 ▶




1




2




3







4











5








6












2




3









4




5






2



3



4





support.stihl.com

© ANDREAS STIHL AG & Co. KG  
0457 374 0006 A A25

Apple and the Apple logo are trademarks of Apple Inc.,  
registered in the U.S. and other countries.  
App Store is a service mark of Apple Inc. Google Play and  
the Google Play logo are trademarks of Google Inc.

