



Cordless Polisher Scrubber PS001G



XGT
40V **Li-ion**
max

Quick, easy, and
effective cleaning



Stable operation is ensured by constant speed control and an anti-wobble structure.

Flexible head

With the two levers loosened, wobbling is reduced.



Springy splash guard


Using the splash guard with the brush or pad prevents water or cleaning agent from splashing.

High power Brushless motor



Constant speed control

enables uniform polishing operations and reduces cleaning inconsistencies.



Brush/Pad replaceable without touching

When using the splash guard



Brush installation

Press the appliance lightly to the floor and pull the switch trigger.

Main power switch



Brush removal

Press the appliance lightly to the floor and pull the switch trigger.

Accessory removing button



Cleaning in bathrooms

Floor pad 200

White
Part No. 191455-9



Red
Part No. 191456-7



Surface polishing of resin wax

Cleaning wall edges/tiled-floor joints

You can use the appliance without the splash guard when cleaning baseboards and other wall edges, tiled-floor joints, or grooves.



When using the appliance without the splash guard, always lock the head of the appliance with levers.



3-speed settings

Selectable from three speed modes according to the work environment and conditions.



Speed mode / No load speed	Application
3. High / 600 min ⁻¹	For polishing smooth and
2. Med. / 350 min ⁻¹	Suitable for various tasks
1. Low / 150 min ⁻¹	For tasks with high resist and for tasks with reduce

a wide range of tasks with a variety of attachments



Brush 190
 Medium
 Part No. 1914T1-4

Cleaning in kitchens



Brush 190
 Soft
 Part No. 1914T0-6

Cleaning on decks




Floor pad 200
 Blue
 Part No. 1914S7-5
 Brown
 Part No. 1914S8-3
 Black
 Part No. 1914S9-1

Cleaning with resin wax
Removing resin wax



LED job lights



Two LED job lights on the head section illuminate a wide area in the direction of travel and the surroundings. (always solid on during operation, with afterglow function)

...d glossy surfaces.
 ...such as wax cleaning and interior floor polishing.
 ...ance on the pad/brush, such as anti-slip floors,
 ...d splashing of liquid.

Adjustable and easy-to-grip handle design

Handle design for easy pushing by applying force

Telescopic pipe adjustable with a lever

- The pole length can be adjusted according to the task and the operator's height. (Total length: 1,081 - 1,435mm)
- The pole can be fixed at any desired position.



Battery cover
 Keeps cleaning agents from adhering to the battery.

Extension range
354 mm



(eXtreme Protection Technology)

Accessories


Brush 190

Brush	Brush bristle type	Application	Part No.
	Soft	For cleaning wooden floors, decks, etc.	1914T0-6
	Medium	For cleaning general interior floors.	1914T1-4
	Hard	For cleaning exterior concrete floors and removing grease stains from kitchens and similar areas.	1914T2-2
	Hard (with abrasive)	For cleaning porcelain tiles and similar surfaces.	1914T3-0



Floor pad

Floor pad	Color*1	Cleaning ability*2	Cleaning surface	Application	Part No.
	White	Low	Smooth	For surface polishing of resin wax.	1914S5-9
	Red				1914S6-7
	Blue	High	Rough	For cleaning of resin wax.	1914S7-5
	Brown			For removing resin wax.	1914S8-3
	Black			1914S9-1	




*1 The brighter and lighter the color, the finer the grit; the darker and deeper the color, the coarser the grit (industry standard).

*2 Stain and wax removal power

Pad holder 175 set

Pad holder for Floor pad 200 (used with Floor pad 200)
Attachment portion for the floor pad: hook and loop fastener

Part No. 1914S4-1



Accessory bag set

An accessory bag made of water-resistant materials for carrying wet accessories. Capable of storing all accessories for this model.

Part No. 1915D1-8



Various pads can be attached to the hook-and-loop side.

Charging Time

	Fast Charging	
	DC40RA	DC40RC
*1 BL4020 2.0Ah	22 min	30 min
*1 BL4025 2.5Ah	28 min	38 min
*1 BL4040/F 4.0Ah	45 min	67 min
BL4050F 5.0Ah	50 min	85 min
BL4080F 8.0Ah	76 min	170 min

*1 Recommended battery

Cordless Polisher Scrubber

PS001G

- Reversing
- Electronic 3-Speed
- Constant Speed
- Soft Start
- Built-in Job Light
- Anti-restart function

No load speed	High: 600 min ⁻¹ , Med.: 350 min ⁻¹ , Low: 150 min ⁻¹
Continuous use	High: 30 min, Med.: 50 min., Low: 140 min
Attachment size	Brush: 190 mm (7-1/2"), Floor pad: 200 mm (7-7/8")
Telescopic pole	1,081 - 1,435 mm (42-1/2 - 56-1/2")
Head height	189 mm (7-7/16")
Vibration level (EN60335-2-67)	2.5 m/s ² or less
Vibration K Factor (EN60335-2-67)	1.5 m/s ²
Sound pressure level (EN60335-2-67)	73 dB(A)
Sound power level (EN60335-2-67)	88 dB(A)
Noise K factor (EN60335-2-67)	3.0 dB(A)
Dimensions (L x W x H)	1,081 - 1,435 x 204 x 361 mm (42-1/2 - 56-1/2 x 8 x 14-1/4")
Net weight	4.4 - 5.6 kg (9.7 - 12.3 lbs.)
Net weight (Battery)	BL4020 - BL4080F

Standard Equipment : Floor pad, Brush, Pad holder, Accessory bag, Splash guard, Battery, Charger

The weight may differ depending on the attachment(s), including the battery cartridge.
Items of standard equipment and specifications may vary by country or area.

Makita Corporation

3-11-8 Sumiyoshi-cho, Anjo, Aichi, 446-8502 Japan

