



## OEM EC36DA

Item No.	Code No.	Description	No. Used	Remarks
1	377703	PAN HEAD SCREW M4X10	8	
2	377719	FRONT PANEL	1	
3	377713	UNLOADING PIPE ASS'Y	1	INCLUD. 4-7, 11
4	377714	UNLOADING TUBE	1	
5	377715	UNLOAD TUBE INTERLINING	2	
6	377717	NUT (B)	1	
7	377718	COPPER RING	2	
8	377712	3-IN-1 PRESSURE SWITCH	1	
9	377756	HOSE BAND	1	
10	377711	CONNECTING HOSE	1	
11	377716	NUT (A)	1	
*12	381345	REGULATING VALVE ASS'Y (EU)	1	INCLUD. 13-18 FOR EUROPE
13	377727	PRESSURE GAUGE	2	
14	377725	REGULATOR KNOB	1	
15	377722	REGULATING VALVE	1	
*16	381347	QUICK COUPLING (EU)	1	FOR EUROPE
*17	377726	SAFETY VALVE	1	FOR EUROPE, AUS
18	377724	ELBOW	1	
19	377720	PAN HEAD SCREW M5	5	
20	377728	HOSE	1	
21	377733	THREE-WAY ELBOW	1	
22	377729	HOUSING (A)	1	
23	377730	PIPE ASS'Y	1	INCLUD. 24, 25
24	377731	EXHAUST PIPE	1	
25	377732	O-RING	2	
26	377735	JOINT	1	
27	377702	PUMP	1	
28	377736	AIR CLEANER	1	
29	377738	PAN HEAD SCREW M6	3	
30	377734	CHECK VALVE	1	
31	377737	PUMP RUBBER	3	
32	377704	CONTROLLER	1	
33	377747	HOUSING (B) ASS'Y	1	INCLUDE. 34-42
34	377755	SELF-TAPPING SCREW ST4. 2X19	2	
35	377754	SUPPORT PLATE	1	
36	377746	SELF-TAPPING SCREW ST4. 2X16	19	
37	377748	BATTERY HOLDER (A)	1	
38	377749	BATTERY PLATE	2	
39	377750	SELF-TAPPING SCREW ST2. 6X8	4	
40	377751	BATTERY TERMINAL (REPAIR)	1	
41	377752	BATTERY HOLDER (B)	1	
42	377753	HOUSING (B)	1	
43	377706	DRAIN VALVE	1	
*44	381344	TANK (EU)	1	FOR EUROPE, AUS
45	377742	PIPE SLEEVE (B)	4	
46	377739	LEFT FRAME	1	
47	377740	CONNECTING PIPE	2	
48	377741	HANDLE GRIP	1	
49	377744	RIGHT FRAME	1	
50	377743	PIPE SLEEVE (A)	4	
51	377707	FLANGE BOLT M6	6	
52	377745	RUBBER FOOT (REAR)	2	
53	377708	FLANGE PAN HEAD SCREW M6	8	

\* ALTERNATIVE PARTS

