



BCEm 5828

BRUSH CUTTER




Spare parts list

Spare parts list BCEm 5825




ORDER CODE	KIT NO.	description	Including positions
60058020201SE01	KIT NO.1	Starter KIT	18,19
60058020201SE02	KIT NO.2	CRANK CASE	20,21,22,27,28,29,53
60058020201SE03	KIT NO.3	CRANK SHAFT ASS'Y	17,23,24,25,26
60058020201SE04	KIT NO.4	PISTON	12,13,14,15,16,34
60058020201SE05	KIT NO.5	CARBURETOR	3,4,5,6,7,8,9,10,11
60058020201SE06	KIT NO.6	Body parts	1,2,30,40,41,42,51,5,54,67
60058020201SE07	KIT NO.7	GASOLINE PUMP	39,62,63,64,65,66
60058020201SE08	KIT NO.8	FUEL TANK CAP	56,57,58,59,60
60058020201SE09	KIT NO.9	FUEL TANK	55
60058020201SE10	KIT NO.10	FLYWHEEL	43,44,45,46
60058020201SE11	KIT NO.11	CLUTCH	47,48,49,50
60058020201SE12	KIT NO.12	IGNITIONCOIL COMP	31,32,33
60058020201SE13	KIT NO.13	MUFFLER	35,36,37,38


Spare parts list BCEm 5825




ORDER CODE	KIT NO.	description
60058020201SB01	KIT NO.1	Gear Case Ass'y



Spare parts list BCEm 5825




ORDER CODE	KIT NO.	description
60058020201SB02	KIT NO.2	Handle




ORDER CODE	KIT NO.	description
60058020201SB03	KIT NO.3	Clutch Drum assy


Spare parts list BCEm 5825




ORDER CODE	KIT NO.	description
60058020201SB04	KIT NO.4	Pipe Comp.




ORDER CODE	KIT NO.	description
60058020201SB05	KIT NO.5	Guard Ass'y




Spare parts list BCEm 5825




ORDER CODE	KIT NO.	description
60058020201SB06	KIT NO.6	Lever Ass'y




ORDER CODE	KIT NO.	description
60058020201SB07	KIT NO.7	Holder Ass'y



Spare parts list BCEm 5825



ORDER CODE	KIT NO.	description
60058020201SB08	KIT NO.8	Nylon Cutter Head



ORDER CODE	KIT NO.	description
60058020201SB10	KIT NO.10	Guard
60058020201SB11	KIT NO.11	Harness Ass'y
60058020201SB12	KIT NO.12	Blade

