



©

Parts List CS1840 CHAINSAW 1

Item	Part Number	Qty	Part Description	General Description	Other Info	Repair Inst	Markets
1	1004700-39	1	CAP SA			No	
2	1004698-02	1	SEAL			No	
3	1004698-03	1	RESERVOIR SA			No	
4	1004698-04	1	CORDSET (EURO)			No	QS
5	1004698-05	1	CORD PROTECTOR			No	
6	1004697-51	2	SCREW			No	
12	1004698-11	1	SPRING			No	
13	1004700-55	1	TRIGGER			No	
14	1004698-13	1	SPRING			No	
15	1004698-14	1	BUTTON			No	
16	1004698-15	1	CONNECTING ROD			No	
17	1004698-16	1	SPRING			No	
19	1004698-18	2	MICRO SWITCH			No	
21	1004698-20	2	NUT			No	
22	1004698-21	1	PINION			No	
23	1004698-22	1	BUSHING			No	
24	1004697-77	11	SCREW			No	
25	1004698-23	1	HOUSING LH			No	
26	1004698-24	1	ARMATURE SA			No	
27	1004698-25	1	SPACER			No	
28	1004698-26	1	CAPACITOR			No	
29	1004698-27	1	FIELD SA			No	
30	1004700-35	2	BRUSH			No	
33	1004698-31	1	COVER REAR			No	
34	1004698-32	2	SCREW			No	
35	1004695-08	2	WASHER			No	
36	1004700-36	1	BRAKE			No	
37	1004698-34	1	PUMP SA			No	
40	1004699-16	1	BOLT			No	
41	1004698-38	2	O RING			No	
42	1004698-39	1	OUTLET			No	
43	1004698-40	1	TUBE OIL			No	
44	1004698-41	1	OUTPUT SHAFT SA			No	

Parts List CS1840 CHAINSAW 1

Item	Part Number	Qty	Part Description	General Description	Other Info	Repair Inst	Markets
45	1004700-37	1	DUST GUARD			No	
46	1004698-43	1	SPRING			No	
47	1004698-25	1	SPACER			No	
48	1004700-38	1	BRAKE			No	
49	1004698-46	1	SLEEVE			No	
50	1004698-47	1	PIN			No	
51	1004698-48	1	CONNECTING ROD			No	
52	1004697-74	1	SCREW			No	
53	1004698-49	1	HOUSING RH			No	
54	1004698-50	1	SPRING			No	
55	1004699-14	1	SPROCKET			No	
56	1004697-79	1	RETAINER			No	
60	1004697-89	1	WRENCH SPECIAL			No	
61	1004698-55	1	CAP			No	
62	1004698-56	1	END CAP SA			No	
63	1004698-89	1	BAR CHAIN 40CM			No	
64	1004698-91	1	SHEATH			No	
65	1004698-90	1	CHAIN	40CM		No	