


## ELECTRIC TOOL PARTS LIST

**CORDLESS RECIPROCATING SAW**  
**Model CR 18DBL**

**2017·4·20**  
**(E1)**



**PARTS**

CR 18DBL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
1	305574	HEX. SOCKET HD. BOLT (W/SP.WASHER) M5 X 16	4	
2	371365	UPPER COVER	1	
3	319874	PACKING (B)	1	
4	371368	SPIRAL RETAINING RING D16	1	
5	371376	BLADE HOLDER	1	
6	371381	SLEEVE	1	
7	371378	HOLDER PIN	1	
8	371379	BLADE SPRING	1	
9	371377	BLADE HOLDER COVER	1	
10	371367	RETAINING RING FOR D13 SHAFT	1	
11	371371	PACKING WASHER	1	
12	371370	FELT PACKING	1	
13	371363	SEAL SLEEVE	1	
14	371369	O-RING	1	
15	371362	METAL (B)	2	
16	371366	PLUNGER (A)	1	
17	371380	PIN	1	
18	371382	BASE	1	
19	371374	BLADE LAVER SHAFT	1	
20	371375	BLADE LEVER SPRING	1	
21	371373	BLADE LEVER	1	
22	371386	FRONT COVER	1	
23	371383	BASE PLATE	1	
24	332662	HEX SOCKET BOLT M5 X 12	2	
25	949216	MACHINE SCREW M4 X 10 (10 PCS.)	1	
26	371929	DISTANCE PIECE	1	
27	371385	FRONT PLATE (A)	1	
28	371384	BASE LEVER	1	
29	986011	TAPPING SCREW (W/SP. WASHER) D5 X 30	4	
30	371364	HOLDER COVER (B)	2	
31	371989	SEAL LOCK HEX. SOCKET HD. BOLT M5 X 14	4	
32	371990	SEAL LOCK HEX. SOCKET HD. BOLT M4 X 12	3	
33	371360	BEARING COVER (B)	1	
34	6901VV	BALL BEARING 6901VV	1	
35	371359	SPINDLE	1	
36	371372	SEAL PACKING (A)	1	
37	983541	CONNECTING PIECE (A)	1	
38	324470	NEEDLE ROLLER	1	
39	371991	SEAL LOCK HEX. SOCKET HD. BOLT M6 X 20	1	
40	371361	GEAR	1	
41	371358	GEAR COVER	1	
42	339250	TAPPING SCREW (W/FLANGE) D4 X 20	10	
43	371387	HOOK	1	
44	371992	SEAL LOCK HEX. SOCKET HD. BOLT M5 X 10	2	
45	361062	ROTOR ASS'Y	1	INCLUD.46
46	606ZZM	BALL BEARING 606VV	1	
47	340968	STATOR FET PCB ASS'Y	1	INCLUD.49
48	951039	MACHINE SCREW (W/SP. WASHER) M4 X 12	2	
49	371357	CONTROLLER TERMINAL SET	1	
50	319760	PUSHING BUTTON	1	

**PARTS**

CR 18DBL

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
51	371356	HANDLE DAMPER	4	
52		NAME PLATE	1	
53	371994	HOUSING SET	1	
54	371995	HANDLE SET	1	
*	55	335791	BATTERY BSL 1850 (USA,CAN)	2 INCLUD.504
*	55	336265	BATTERY BSL 1850 (CHN)	2 INCLUD.504
*	55	338891	BATTERY BSL 1860 (EUROPE,AUS,NZL)	2 INCLUD.504
*	55	338890	BATTERY BSL 1860 (USA,CAN)	1 INCLUD.504

**STANDARD ACCESSORIES**

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
*	501	370683	CURVED BLADES NO.141(S)150L P.14 (3 PCS.)	1
*	501	371902	CURVED BLADES NO.158 200L P.8 (3 PCS.)	1 FOR USA,CAN
*	502		CHARGER (MODEL UC 18YFSL)	1
*	502		CHARGER (MODEL UC 18YSL3)	1
*	502		CHARGER (MODEL UC 18YML2)	1
	503	371355	CASE	1
	504	329897	BATTERY COVER	1

**OPTIONAL ACCESSORIES**

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
	601	959611	SABER SAW BLADES NO.4 (5 PCS.)	1
	602	958185	SABER SAW BLADES NO.5 (5 PCS.)	1
	603	959799	SABER SAW BLADES NO.95 (3 PCS.)	1
	604	959800	SABER SAW BLADES NO.96 (3 PCS.)	1
	605	318611	SABER SAW BLADES NO.101 150L P.10 (5 PCS.)	1
	606	318612	SABER SAW BLADES NO.102 228L P.10 (5 PCS.)	1
	607	318613	SABER SAW BLADES NO.103 150L P.14 (5 PCS.)	1
	608	318614	SABER SAW BLADES NO.104 228L P.14 (5 PCS.)	1
	609	318617	SABER SAW BLADES NO.107 150L P.24 (5 PCS.)	1
	610	318618	SABER SAW BLADES NO.108 228L P.24 (5 PCS.)	1
	611	324818	SABER SAW BLADES NO.109 150L P.18 (5 PCS.)	1
	612	324819	SABER SAW BLADES NO.110 228L P.18 (5 PCS.)	1
	613	318619	SABER SAW BLADES NO.121 305L P.6 (5 PCS.)	1
	614	318620	SABER SAW BLADES NO.131 305L P.10/14(5 PCS.)	1
	615	318621	SABER SAW BLADES NO.132 203L (5 PCS.)	1
	616	370684	CURVED BLADES NO.142(S)200L P.14 (3 PCS.)	1
	617	370685	CURVED BLADES NO.143(S)250L P.14 (3 PCS.)	1