





STIHL®

4241 007 1003


0457 364 0031 C L17




1




2




3



4




5



BG 45
 BG 46
 BG 55
 BG 65
 BG 85
 SH 55
 SH 85

6



BG 56 SH 56
 BG 66 SH 86
 BG 86 SHE 71
 BGE 61 SHE 81
 BGE 71
 BGE 81

7

