



# Einhell

## PROFESSIONAL



Cordless Belt Sander

**TP-BS 18/457 Li BL - Solo**

Item No.: 4466270

Ident No.: 21011

Bar Code: 4006825663624

The Einhell cordless belt sander TP-BS 18/457 Li BL is a practical tool for evenly sanding large areas. The 18 V device is part of the combinable Power X-Change family. With its brushless motor, its 126x75 mm sanding surface, a max. sanding belt speed of 250 m/min and the continuous running lock, the cordless belt sander quickly processes even large areas. The sander is also provided with tool-free sanding belt installation & adjustment, an additional handle and a storage surface for stationary use. It has dust extraction and an extraction adapter. Delivery incl. dust collection box and 3x P80 sanding belts. Battery and charger sold separately.

## Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Brushless motor - more power and longer running time
- Electronic speed control for material- & usage-oriented work
- Tool-free sanding belt change thanks to locking lever
- Precise belt running through sanding belt adjustment
- Handle and additional handle with soft grip for optimal handling
- Integrated storage surface for stationary use
- Continuous running lock for comfortable working
- Integrated dust extraction and extraction adapter
- Dust box for dust-free workplace
- Incl. 3x sanding belt (P80)
- Supplied without battery and without charger (sold separately)



## Technical Data

- Belt speed 120 - 250 m/min
- Abrasive belt 457 x 75 mm
- Grinding surface 126x75 mm

## Logistic Data

- Product weight (kg) 2.58
- Gross weight (kg) 3.33
- Dimensions single packaging 355 x 170 x 200 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 15.5 kg
- Dimensions export carton 335 x 385 x 405 mm
- Container quantity (20"/40"/40"HC) 2080 | 4048 | 4800



## Available as special accessories



2x 3,0Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512083  
Bar Code: 4006825638509  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



Schleifbandset, 75x457, 6tlg.  
Belt Sander Accessory  
Item No.: 4419815  
Bar Code: 4006825665819  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB  
Battery  
Item No.: 4511524  
Bar Code: 4006825656206  
Einhell Accessory



5,2Ah & 4A Fastcharger  
PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory

# Battery-Running-Times




One Battery for All

sanding<sup>1)</sup>  
(min.)

1.5 Ah	11
2.0 Ah	15
2.5 Ah	18
3.0 Ah	22
4.0 Ah	30
5.2 Ah	38
6.0 Ah	44
8.0 Ah	59

Test setup:

1) no-load - Max. electronic speed



МАГАЗИН МАЙСТОРА®  
БАШ ПРОФЕСИОНАЛНИ РЕШЕНИЯ