



Nothing but **HEAVY DUTY.**[®]



M12 FHIR14 M12 FHIR38






Original instructions
Originalbetriebsanleitung
Notice originale
Istruzioni originali
Manual original
Oorspronkelijke gebruiksaanwijzing
Original brugsanvisning
Original bruksanvisning
Bruksanvisning i original
Alkuperäiset ohjeet





Πρωτότυπο οδηγιών χρήστης
Orijinal işletme talimatı
Původním návodem k používání
Pôvodný návod na použitie
Instrukcja oryginalną
Eredeti használati utasítás
Izvirna navodila
Originalne pogonske upute
Instrukcijām oriģinālvalodā
Originalni instrukcija

Algupärane kasutusjuhend
Оригинальное руководство по эксплуатации
Оригинално ръководство за експлоатация
Instrucțiuni de folosire originale
Оригинален прирачник за работа
Оригинал інструкції з експлуатації
التعليمات الأصلية

МАГАЗИН
БАШИ МАЙСТОРА
профессиональные решения

| | | | | | |
|--------------------|--|---|----------|---|-----------|
| ENGLISH | | Picture section with operating description and functional description | 4 | Text section with Technical Data, important Safety and Working Hints and description of Symbols | 14 |
| DEUTSCH | | Bildteil mit Anwendungs- und Funktionsbeschreibungen | 4 | Textteil mit Technischen Daten, wichtigen Sicherheits- und Arbeitshinweisen und Erklärung der Symbole. | 16 |
| FRANÇAIS | | Partie imagée avec description des applications et des fonctions | 4 | Partie textuelle avec les données techniques, les consignes importantes de sécurité et de travail ainsi que l'explication des pictogrammes. | 18 |
| ITALIANO | | Sezione illustrata con descrizione dell'applicazione e delle funzioni | 4 | Sezione testo con dati tecnici, importanti informazioni sulla sicurezza e sull'utilizzo, spiegazione dei simboli. | 20 |
| ESPAÑOL | | Sección de ilustraciones con descripción de aplicación y descripción funcional | 4 | Sección de texto con datos técnicos, indicaciones importantes de seguridad y trabajo y explicación de los símbolos. | 22 |
| PORTUGUES | | Parte com imagens explicativas contendo descrição operacional e funcional | 4 | Parte com texto explicativo contendo Especificações técnicas, Avisos de segurança e de operação e a Descrição dos símbolos. | 24 |
| NEDERLANDS | | Beeldgedeelte met toepassings- en functiebeschrijvingen | 4 | Tekstgedeelte met technische gegevens, belangrijke veiligheids- en arbeidsinstructies en verklaring van de symbolen. | 26 |
| DANSK | | Billeddel med anvendelses- og funktionsbeskrivelser | 4 | Tekstdel med tekniske data, vigtige sikkerheds- og arbejdsanvisninger og forklaring af symbolene. | 28 |
| NORSK | | Bilde del med bruks- og funksjonsbeskrivelse | 4 | Tekstdel med tekniske data, viktige sikkerhets- og arbeidsinstruksjoner og forklaring av symbolene. | 30 |
| SVENSKA | | Bilddel med användnings- och funktionsbeskrivning | 4 | Textdel med tekniska informationer, viktiga säkerhets- och användningsinstruktioner samt symbolförklaringar. | 32 |
| SUOMI | | Kuvatavut käytö- ja toimintakuvaus | 4 | Tekstisivut: tekniset tiedot, tärkeät turvallisuus- ja työskentelyohjeet sekä merkkien selitykset. | 34 |
| ΕΛΛΗΝΙΚΑ | | Τμήμα εικόνων με περιγραφές χρήσης και λειτουργίας | 4 | Τμήμα κειμένου με τεχνικά χαρακτηριστικά, σημαντικές υποδείξεις ασφαλείας και εργασίας και εξήγηση των συμβόλων. | 36 |
| TÜRKÇE | | Resim bölümü Uygulama ve fonksiyon açıklamaları ile birlikte | 4 | Teknik bilgileri, önemli güvenlik ve çalışma açıklamalarını ve de sembollerin açıklamalarını içeren metin bölümü. | 38 |
| ČESKY | | Obrazová část s popisem aplikací a funkcí | 4 | Textová část s technickými daty, dôležitými bezpečnostními a pracovními pokyny a s vysvetlivkami symbolů | 40 |
| SLOVENSKY | | Obrazová časť s popisom aplikácií a funkcií | 4 | Textová časť s technickými dátami, dôležitými bezpečnostními a pracovními pokynmi a s vysvetlivkami symbolov | 42 |
| POLSKI | | Część rysunkowa z opisami zastosowania i działania | 4 | Część opisowa z danymi technicznymi, ważnymi wskazówkami dotyczącymi bezpieczeństwa i pracy oraz objaśnieniami symboli. | 44 |
| MAGYAR | | Képes részalkalmazási- és működési leírásokkal | 4 | Szöveges rész műszaki adatokkal, fontos biztonsági- és munkavégzési útmutatókkal, valamint a szimbólumok magyarázata. | 46 |
| SLOVENSKO | | Del slikez opisom uporabe in funkcij | 4 | Del besedila s tehničnimi podatki, pomembnimi varnostnimi opozorili in delovnimi navodili in pojasnilni simbolov. | 48 |
| HRVATSKI | | Dio sa slikama opisima primjene i funkcija | 4 | Dio štiva sa tehničkim podacima, važnim sigurnosnim i radnim uputama i objašnjenjem simbola. | 50 |
| LATVISKI | | Attēla daļa ar lietšanas un funkciju aprakstiem | 4 | Teksta daļa ar tehniskajiem parametriem, svarīgiem drošības un darbības norādījumiem, simbolu atšifrējumiem. | 52 |
| LIETUVIŠKAI | | Paveikslėlio dalissu vartojimo instrukcija ir funkcijų aprašymais | 4 | Teksto dalis su techniniais duomenimis, svarbiomis saugumo ir darbo instrukcijomis bei simbolių paaškinimais. | 54 |
| EESTI | | Pildiosa kasutusjuhendi ja funktsioonide kirjeldusega | 4 | Tekstiossa teknillistate näitäjate, oluliste ohutus- ja tööjuhenditega ning sümbolite kirjeldustega. | 56 |
| РУССКИЙ | | Раздел иллюстраций с описанием эксплуатации и функций | 4 | Текстовый раздел, включающий технические данные, важные рекомендации по безопасности и эксплуатации, а также описание используемых символов. | 58 |
| БЪЛГАРСКИ | | Част със снимки с описание за приложение и функции | 4 | Част с текст с технически данни, важни указания за безопасност и работа и разяснение на символите. | 60 |
| ROMÂNIA | | Secvența de imagine cu descrierea utilizării și a funcționării | 4 | Portiune de text cu date tehnice, indicații importante privind siguranța și modul de lucru și descrierea simbolurilor. | 62 |
| МАКЕДОНСКИ | | Дел со слика со описи за употреба и функционирање | 4 | Текстуален дел со Технички карактеристики, важни безбедносни и работни упатства и објаснување на символите. | 64 |
| УКРАЇНСЬКА | | Частина з зображеннями з описом робіт та функцій | 4 | Текстова частина з технічними даними, важливими вказівками з техніки безпеки та експлуатації і поясненням символів. | 66 |
| عربی | | قسم الصور يوجد به الوصف التشغيلي والوظيفي | 4 | القسم النصي المزود ببيانات الفنية والنصائح الهمة للسلامة والعمل ووصف الرموز | 71 |





Remove the battery pack before starting any work on the machine.

Vor allen Arbeiten an der Maschine den Wechselakkku herausnehmen

Avant tous travaux sur la machine retirer l'accu interchangeable.

Prima di iniziare togliere la batteria dalla macchina.

Retire la batería antes de comenzar cualquier trabajo en la máquina.

Antes de efectuar qualquer intervenção na máquina retirar o bloco acumulador.

Voor alle werkzaamheden aan de machine de akku verwijderen.

Ved arbejde inden i maskinen, bør batteriet tages ud.

Ta ut vekselbatteriet før du arbeider på maskinen.

Drag ur batteripaket innan arbete utföres på maskinen.

Tarkista pistotulppa ja verkkojohto mahdollisilta vaurioilta. Viat saa korjata vain alan erikoismissä.

Πριν από κάθε εργασία στη μηχανή αφαιρέστε την ανταλλακτική μπαταρία.

Aletin kendinde bir çalışma yapmadan önce kartuş aküyü çıkarın.

Před zahájením veškerých prací na vrtacím šroubováku vyjmout výměnný akumulátor.

Pred každou prácou na stroji výmenný akumulátor vytiahnut.

Przed przygotowaniem do jakichkolwiek prac na elektronarzędziu należy wyjąć wkładkę akumulatorową.

Karbantartás, javítás, tisztítás, stb. előtt az akkumulátort ki kell venni a készülékből.

Pred deli na stroju izvlecite izmenljivi akumulatori.

Prije svih radova na stroju izvaditi bateriju za zamjenu.

Pirms mašīnai veikt jebkādu veida apkopes darbus, ir jāizņem āra akumulātors.

Prieš atlikdam bet kokius darbus ienginyje, išimkite keičiamą akumulatorių.

Enne kõiki töid masina kallal võtke vahetatav aku välja.

Выньте аккумулятор из машины перед проведением с ней каких-либо манипуляций.




Преди започване на каквито е да е работи по машината извадете акумулатора.




Scoateți acumulatorul înainte de a începe orice intervenție pe mașină.


Отстранете ја батеријата пред да започнете да ја користите машината.

Перед будь-якими роботами на машині змінну акумуляторну батарею.


قم بإزالة حزمة البطارية قبل البدء في أي أعمال على الجهاز.








Handle (insulated gripping surface)
Handgriff (isolierte Grifffläche)
Poignée (surface de prise isolée)
Impugnatura (superficie di presa isolata)
Empuñadura (superficie de agarre con aislamiento)
Manípulo (superficie de pega isolada)
Handgrip (geisoleerd)
Håndtag (isolerede gribeflader)
Håndtak (isolert gripeflate)
Handtag (isolerad greppytta)
Kahva (eristetty tarttumapinta)
Χειρολαβή (μονωμένη επιφάνεια λαβής)
El kulpu (izolasyonlu tutma yüzeyi)
Rukojet' (izolovaná uchopovací plocha)
Rukoväť (izolovaná úchopná plocha)
Uchwyt (z izolowaną powierzchnią)
Fogantyú (szigetelt fogófelület)
Ročaj (izolirana prijema površina)
Rukohvat (izolirana površina za držanje)
Rokturis (izolēta satversanas virsma)
Rankena (izoliuotas rankenos paviršius)
Käepide (isoleeritud pideme piirkond)
Рукоятка (изолированная поверхность ручки)
Ръкохватка (изолирана повърхност за хващане)
Mâner (suprafată de prindere izolată)
Дршка (изолирана површина)
Ручка (изолювана поверхня ручки)
المقبض (مساحة المقبض معزولة)





МАГАЗИН
БАШИ МАЙСТОРА®
профессиональные решения

TECHNICAL DATA CORDLESS INDUSTRIAL SCREWDRIVER

| | M12 FHIR14 | M12 FHIR38 |
|--|-----------------------------------|-----------------------------------|
| Production code..... | 4830 62 01000001-999999 | 4830 69 01000001-999999 |
| Tool reception | 1/4" (6,35 mm)..... | 3/8" (9,5 mm)..... |
| No-load speed | 0-450 min ⁻¹ | 0-450 min ⁻¹ |
| Torque max | 47,5 Nm | 47,5 Nm |
| Battery voltage | 12 V | 12 V |
| Weight according EPTA-Procedure 01/2014 (Li-Ion 2,0 Ah ... 6,0 Ah) | 0,96-1,20 kg | 0,96-1,20 kg |
| Recommended ambient operating temperature | -18°C ... +50°C | -18°C ... +50°C |
| Recommended battery types | M12B | M12B |
| Recommended charger | C12C, M12C4, M12-18 | C12C, M12C4, M12-18 |

Noise/vibration information

Measured values determined according to EN 62841.

Typically, the A-weighted noise levels of the tool are:

| | | |
|---|--------------------|--------------------|
| Sound pressure level (Uncertainty K=3dB(A)) | 84,26 dB (A) | 84,26 dB (A) |
| Sound power level (Uncertainty K=3dB(A)) | 95,26 dB (A) | 95,26 dB (A) |

Wear ear protectors!

Total vibration values (vector sum in the three axes) determined according to EN 62841.

Vibration emission value a_v:

| | | |
|--|-----------------------------|-----------------------------|
| Impact tightening of fasteners of the maximum capacity of the tool | 2,88 m/s ² | 2,88 m/s ² |
| Uncertainty K = | 1,50 m/s ² | 1,50 m/s ² |

WARNING

The vibration and noise emission level given in this information sheet has been measured in accordance with a standardized test given in EN 62841 and may be used to compare one tool with another. It may be used for a preliminary assessment of exposure.

The declared vibration and noise emission level represents the main applications of the tool. However if the tool is used for different applications, with different accessories or poorly maintained, the vibration and noise emission may differ. This may significantly increase the exposure level over the total working period.

An estimation of the level of exposure to vibration and noise should also take into account the times when the tool is switched off or when it is running but not actually doing the job. This may significantly reduce the exposure level over the total working period.

Identify additional safety measures to protect the operator from the effects of vibration and/or noise such as: maintain the tool and the accessories, keep the hands warm, organization of work patterns.

WARNING Read all safety warnings, instructions, illustrations and specifications provided with this power tool.

Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

IMPACT DRIVER SAFETY WARNINGS

Hold the power tool by insulated gripping surfaces, when performing an operation where the fastener may contact hidden wiring. Fasteners contacting a "live" wire may make exposed metal parts of the power tool "live" and could give the operator an electric shock.

Wear ear protectors. Exposure to noise can cause hearing loss.

ADDITIONAL SAFETY AND WORKING INSTRUCTIONS

Use protective equipment. Always wear safety glasses when working with the machine. The use of protective clothing is recommended, such as dust mask, protective gloves, sturdy non-slip footwear, helmet and ear defenders.

The dust produced when using this tool may be harmful to health.

Do not inhale the dust. Wear a suitable dust protection mask.

Do not machine any materials that present a danger to health (e.g. asbestos).

Switch the device off immediately if the insertion tool stalls! Do not switch the device on again while the insertion tool is stalled, as doing so could trigger a sudden recoil with a high reactive force. Determine why the insertion tool stalled and rectify this, paying heed to the safety instructions.

The possible causes may be:

- it is tilted in the workpiece to be machined
- it has pierced through the material to be machined
- the power tool is overloaded

Do not reach into the machine while it is running.

The insertion tool may become hot during use.

- when changing tools

- when setting the device down

Chips and splinters must not be removed while the machine is running.

When working in walls ceiling, or floor, take care to avoid electric cables and gas or water pipes.

Clamp your workpiece with a clamping device. Unclamped workpieces can cause severe injury and damage.

Remove the battery pack before starting any work on the machine.

Do not dispose of used battery packs in the household refuse or by burning them. Milwaukee Distributors offer to retrieve old batteries to protect our environment.

Do not store the battery pack together with metal objects (short circuit risk).

Use only System M12 chargers for charging System M12 battery packs. Do not use battery packs from other systems.

Never break open battery packs and chargers and store only in dry rooms. Keep dry at all times.

Battery acid may leak from damaged batteries under extreme load or extreme temperatures. In case of contact with battery acid wash it off immediately with soap and water. In case of eye contact rinse thoroughly for at least 10 minutes and immediately seek medical attention.

Warning! To reduce the risk of fire, personal injury, and product damage due to a short circuit, never immerse your tool, battery pack or charger in fluid or allow a fluid to flow inside them. Corrosive or conductive fluids, such as seawater, certain industrial chemicals, and bleach or bleach containing products, etc., can cause a short circuit.

SPECIFIED CONDITIONS OF USE

The cordless industrial screwdriver can be used to tighten and loosen nuts and bolts wherever no mains connection is available. Do not use this product in any other way as stated for normal use.

EC-DECLARATION OF CONFORMITY

We declare under our sole responsibility that the product described under "Technical Data" fulfills all the relevant regulations and the directives 2011/65/EU (RoHS), 2014/30/EU, 2006/42/EC, and the following harmonized standards have been used:

EN 62841-1:2015
EN 62841-2-2:2014
EN 55014-1:2017+A11:2020
EN 55014-2:2015
EN IEC 63000:2018
Winnenden, 2020-10-27

Alexander Krug
Managing Director



Authorized to compile the technical file.

Techtronic Industries GmbH
Max-Eyth-Straße 10
71364 Winnenden
Germany

GB-DECLARATION OF CONFORMITY

We declare as the manufacturer under our sole responsibility that the product described under "Technical Data" fulfills all the relevant provisions of the following Regulations S.I. 2008/1597 (as amended), S.I. 2016/1091 (as amended), S.I. 2012/3032 (as amended) and that the following designated standards have been used:

BS EN 62841-1:2015
BS EN 62841-2-2:2014
BS EN 55014-1:2017+A11:2020
BS EN 55014-2:2015
BS EN IEC 63000:2018
Winnenden, 2020-10-27

Alexander Krug
Managing Director
Authorized to compile the technical file.

Techtronic Industries GmbH
Max-Eyth-Straße 10
71364 Winnenden
Germany

BATTERIES

Battery packs which have not been used for some time should be recharged before use.

Temperatures in excess of 50°C (122°F) reduce the performance of the battery pack. Avoid extended exposure to heat or sunshine (risk of overheating).

The contacts of chargers and battery packs must be kept clean. For an optimum life-time, the battery packs have to be fully charged, after used.

To obtain the longest possible battery life remove the battery pack from the charger once it is fully charged.

For battery pack storage longer than 30 days:

Store the battery pack where the temperature is below 27°C and away from moisture

Store the battery packs in a 30% - 50% charged condition

Every six months of storage, charge the pack as normal.

BATTERY PACK PROTECTION

In extremely high torque, binding, stalling and short circuit situations that cause high current draw, the tool will vibrate for about 5 seconds, the fuel gauge will flash, and then the tool will turn OFF. To reset, release the trigger.

Under extreme circumstances, the internal temperature of the battery pack could raise too much. If this happens, the fuel gauge will flash until the battery pack cooled down. After the lights go off, the work may continue.

TRANSPORTING LITHIUM BATTERIES

Lithium-ion batteries are subject to the Dangerous Goods Legislation requirements.

Transportation of those batteries has to be done in accordance with local, national and international provisions and regulations.

- The user can transport the batteries by road without further requirements.
- Commercial transport of Lithium-Ion batteries by third parties is subject to Dangerous Goods regulations. Transport preparation and transport are exclusively to be carried out by appropriately trained persons and the process has to be accompanied by corresponding experts.

When transporting batteries:

- Ensure that battery contact terminals are protected and insulated to prevent short circuit.
 - Ensure that battery pack is secured against movement within packaging.
 - Do not transport batteries that are cracked or leak.
- Check with forwarding company for further advice

MAINTENANCE

Use only Milwaukee accessories and spare parts. Should components need to be replaced which have not been described, please contact one of our Milwaukee service agents (see our list of guarantee/service addresses).

If needed, an exploded view of the tool can be ordered. Please state the machine type printed as well as the six-digit No. on the label and order the drawing at your local service agents or directly at: Techtronic Industries GmbH, Max-Eyth-Straße 10, 71364 Winnenden, Germany.

SYMBOLS



CAUTION! WARNING! DANGER!



Remove the battery pack before starting any work on the machine.



Please read the instructions carefully before starting the machine.



Do not dispose electric tools, batteries/rechargeable batteries together with household waste material. Electric tools and batteries that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility. Check with your local authority or retailer for recycling advice and collection point.

n₀

No-load speed

V

Volts

—

Direct current



European Conformity Mark)



British Conformity Mark



Ukraine Conformity Mark



EurAsian Conformity Mark



Copyright 2020
Techtronic Industries GmbH
Max-Eyth-Str. 10
71364 Winnenden
Germany
+49 (0) 7195-12-0
www.milwaukeetool.eu

Techtronic Industries (UK) Ltd
Fieldhouse Lane
Marlow Bucks SL7 1HZ
UK

МАГАЗИН
БАШІ МАЙСТОРА®
профессиональни решениі

