



# Einhell

## EXPERT

### POWER X-CHANGE

Cordless Garden Pump

**AQUINNA 18/28**

**Item No.: 4180440**

Ident No.: 21012

Bar Code: 4006825668711

The Einhell cordless garden pump AQUINNA 18/28 is a powerful pump from the flexibly combinable Power X-Change family for cordless use. It has an ECO mode for maximum runtime and a BOOST mode for maximum power. In addition, the garden pump is equipped with a large water filler screw for filling and a drainage screw for frost protection. The slim and compact cordless pump is easily transported via the carrying handle and fixed to a permanent place of use with the help of the fastening holes. It is equipped with two robust metal threaded connections. Delivery does not include battery or charger.

## Features & Benefits

- Member of the Power X-Change family, 1x 18V battery required
- Power level switch: ECO and BOOST mode
- Practical water filler screw for easy filling
- Frost protection thanks to easy draining via water drain plug
- Overload protection protects the motor from overheating damage
- High-quality, durable suction & pressure connection made of metal
- Easy transport and high mobility thanks to carrying handle
- Pump base with hole for secure, permanent mounting
- Robust mechanical seals for a long service life
- Supplied without battery and charger (sold separately)



## Technical Data

- Max. delivery capacity 2800 L/h
- Max. suction height 6 m
- Max. delivery height / - pressure 25 m / 2.5 bar
- Max. water temperature 35 °C
- Connection suction side 33,3mm (R1 AG)
- Connection pressure side 33,3mm (G1 IG)



## Logistic Data

- Product weight (kg) 2.55
- Gross weight (kg) 3.3
- Dimensions single packaging 476 x 185 x 250 mm
- Pieces per export carton 4 Pieces
- Gross weight of export carton 11.2 kg
- Dimensions export carton 485 x 380 x 510 mm
- Container quantity (20"/40"/40"HC) 1152 | 2320 | 2900



## Available as special accessories



Suction hose 4 m, plastics  
Pump Accessory  
Item No.: 4173635  
Bar Code: 4006825549058  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 2,5Ah Power X-Change  
Battery  
Item No.: 4511516  
Bar Code: 4006825650518  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



Power X-Car Charger 3A  
Charger  
Item No.: 4512113  
Bar Code: 4006825655377  
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack  
Battery  
Item No.: 4511526  
Bar Code: 4006825656695  
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1  
Battery  
Item No.: 4511489  
Bar Code: 4006825638578  
Einhell Accessory



18V 4,0Ah Power-X-Change Plus  
Battery  
Item No.: 4511553  
Bar Code: 4006825660869  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



accessorysetsuction&press(OFF)  
Pump Accessory  
Item No.: 4173763  
Bar Code: 4006825663273  
Einhell Accessory



Power X-Caravan Charger 3A  
Charger  
Item No.: 4512136  
Bar Code: 4006825664010  
Einhell Accessory



Suction hose 7 m, plastics  
Pump Accessory  
Item No.: 4173645  
Bar Code: 4006825549102  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



2x2 Power X-Quattrocharger 4A  
Charger  
Item No.: 4512102  
Bar Code: 4006825649536  
Einhell Accessory



Power X-Fastcharger 4A  
Charger  
Item No.: 4512103  
Bar Code: 4006825650228  
Einhell Accessory



2x 5,2Ah & Twincharger Kit  
PXC-Starter-Kit  
Item No.: 4512108  
Bar Code: 4006825652376  
Einhell Accessory



18V Battery Charger 3,0A - PXC  
Charger  
Item No.: 4514095  
Bar Code: 4006825655292  
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1  
PXC-Starter-Kit  
Item No.: 4512112  
Bar Code: 4006825655766  
Einhell Accessory



5,2Ah & 4A Fastcharger  
PXC-Starter-Kit  
Item No.: 4512114  
Bar Code: 4006825656787  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



Adapter 33,3 mm (1") AG  
Pump Accessory  
Item No.: 4173761  
Bar Code: 4006825662733  
Einhell Accessory



accessorysetpressureside (OFF)  
Pump Accessory  
Item No.: 4173762  
Bar Code: 4006825663266  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511600  
Bar Code: 4006825665055  
Einhell Accessory



Saugschlauch 7 m Messing  
Pump Accessory  
Item No.: 4173640  
Bar Code: 4006825549171  
Einhell Accessory





18V 4-6Ah & 6A Boostcharger  
PXC-Starter-Kit  
Item No.: 4512143  
Bar Code: 4006825667653  
Einhell Accessory



Saugschlauch 4 m Messing  
Pump Accessory  
Item No.: 4173630  
Bar Code: 4006825549133  
Einhell Accessory

## Battery-Running-Times

One Battery for All	 pumping water (boost) <sup>1</sup> (min.)	 pumping water (eco) <sup>2</sup> (min.)
	1.5 Ah	10
2.0 Ah	14	18
2.5 Ah	17	22
3.0 Ah	20	27
4.0 Ah	28	36
5.2 Ah	36	47
6.0 Ah	40	54
8.0 Ah	56	72

### Test setup:

- 1) BOOST
- 2) ECO

