



# Einhell

# CLASSIC

## POWER X-CHANGE

Cordless Orbital Sander

**TC-OS 18/187 Li Solo**

**Item No.: 4460725**

Ident No.: 11018

Bar Code: 4006825642735

The Einhell TC-OS 18/187 Li Solo cordless orbital sander is a light and handy orbital sander from the PXC family, with all the advantages of the flexible, completely interchangeable system series. The orbital sander is ideally suited for grinding/sanding flat surfaces. Thanks to the micro hook-and-loop fastening and clamping device, changing the abrasive paper is quick and easy, but sheets of abrasive paper without hook-and-loop fastening can also be clamped. For comfortable handling it has large grip surfaces with soft grips. For a clean workplace there is a dust bag and an adapter for a vacuum cleaner included. The product is supplied complete with one sheet of abrasive paper. Supplied without a rechargeable battery or charger.

## Features & Benefits

- Member of the Power X-Change family
- Light, handy orbital sander
- Ideally suited for sanding flat surfaces
- Easy abrasive paper change using micro hook-and-loop fastening
- Also suitable for abrasive paper without hook-and-loop fastening
- Comfortable to handle thanks to large grip areas and soft grip
- Dust bag collects dust from sanding
- Suitable for connecting to an external dust extractor
- Incl. 1 sheet of abrasive paper so you can get started right away
- Supplied without battery and charger (available separately)




## Technical Data

- Oscillating speed 24000 min<sup>-1</sup>
- Oscillating circuit 2 mm
- Sanding area 187 x 90 mm
- Sandpaper size hook and loop connection 187 x 94 mm
- Sandpaper size clamp-connection 237 x 94 mm



## Logistic Data

- Product weight (kg) 1.17
- Gross weight (kg) 1.59
- Dimensions single packaging 225 x 161 x 111 mm
- Pieces per export carton 8 Pieces
- Gross weight of export carton 12.8 kg
- Dimensions export carton 470 x 240 x 335 mm
- Container quantities (20"|40"|40"HC) 5184 | 10800 | 12600



## Available as special accessories



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



18V 2,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512040  
Bar Code: 4006825613681  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



15 Q-Stick Schleifst. 187x93mm  
Schwingschleifer-Zubehör  
Item No.: 49817985  
Bar Code: 4009318179855  
Einhell Accessory



18V 3,0 Ah Power-X-Change 2  
Battery  
Item No.: 4511341  
Bar Code: 4006825590593  
Einhell Accessory

## Battery-Running-Times



running time<sup>1</sup>  
(min.)

One Battery for All

Capacity (Ah)	Running Time (min.)
1.5 Ah	25
2.0 Ah	34
2.5 Ah	42
3.0 Ah	50
4.0 Ah	67
5.2 Ah	87
6.0 Ah	100
8.0 Ah	134

Test setup:

1) no-load

