







Cordless Multiple Sander

TE-OS 18/150 Li Solo

Item No.: 4460708

Ident No.: 21020

Bar Code: 4006825651218

The cordless multiple sander TE-OS 18/150 Li - Solo is a compact and handy sander from Power X-Change family of devices which combines the best ergonomics with maximum functionality for lending surfaces a good finish. The ergonomic grip area with soft grip is good to hold. Experts appreciate the tool as an indispensable helper which really demonstrates its strengths particularly on small and hard-to-reach surfaces. The tool is supplied without battery and charger but it can be powered by Power X-Change rechargeable batteries.

Features & Benefits

- Member of the Power X-Change family
- Grip area with softgrip modeled on the palm of a hand
- Small, compact and easy to handle
- Flexible in use for sanding corners and small surfaces
- "Extreme Fix" fastening for quick change of abrasive paper
- High removal rate with "Extreme Fix" due to reduced slippage
- Solid, rugged aluminium fan impeller for smooth running
- Active dust extraction keeps the work area clean
- Filter box for sanding dust (only 1.5/2.0/2.5/2.6/3.0+Ah batt.)
- Incl. vacuum cleaner adapter (with every battery usable)
- Incl. six sheets of abrasive paper (3*P120/3*P240)
- Supplied without battery and charger (available separately)

Technical Data

- Oscillating speed 24000 min^-1 - Oscillating circuit 1.6 mm

150 x 150 x 100 mm - Grinding (sanding) surface (delta) - Sanding paper size 150 x 150 x 100 mm

Logistic Data

- Product weight (kg) - Gross weight (kg)

- Dimensions single packaging

- Pieces per export carton - Gross weight of export carton

- Dimensions Export Carton

- Container quantity (20"/40"/40"HC)

0.79

1.14

257 x 157 x 110 mm

8 Pieces

9.95 kg

515 x 265 x 340 mm

4224 | 8448 | 9856






















Available as special accessories



2x 3,0Ah & Twincharger Kit PXC-Starter-Kit Item No.: 4512083 Bar Code: 4006825638509

Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit Item No.: 4512097 Bar Code: 4006825646962 Einhell Accessory

18V 4,0Ah Power X-Change 1 Battery Item No.: 4511396

Bar Code: 4006825610376 Einhell Accessory

18V 2,5Ah Power X-Change Battery Item No.: 4511516

Bar Code: 4006825650518 Einhell Accessory

18V 5,2Ah Power X-Change Plus Battery Item No.: 4511437 Bar Code: 4006825616606

Einhell Accessory

2x18V 4,0Ah PXC-Twinpack CB 1 Battery Item No.: 4511489

Bar Code: 4006825638578 Einhell Accessory

18V 3,0Ah Power X-Change Plus Battery Item No.: 4511501

Bar Code: 4006825644197 Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus Battery Item No.: 4511502

Bar Code: 4006825644210 **Einhell Accessory**

18V 2,0Ah Power X-Change Battery Item No.: 4511395 Bar Code: 4006825610369 Einhell Accessory

18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit Item No.: 4512042 Bar Code: 4006825613704 Einhell Accessory

Power X-Fastcharger 4A Charger Item No.: 4512103 Bar Code: 4006825650228 Einhell Accessory

> Power X-Twincharger 3A Charger Item No.: 4512069 Bar Code: 4006825629729 Einhell Accessory

> Power X-Boostcharger 6A Charger Item No.: 4512064 Bar Code: 4006825629019 **Einhell Accessory**

15 Q-Stick Schleifd. 150x100mm Multischleifer-Zubehör Item No.: 49496174 Bar Code: 4009314961744 Einhell Accessory









Battery-Running-Times

One Battery for All	sanding ¹	
One Battery for Air	(min.)	
1.5 Ah	23	
2.0 Ah	27	
2.5 Ah	34	
3.0 Ah	40	
4.0 Ah	55	
5.2 Ah	70	
6.0 Ah	80	
8.0 Ah	110	

Test setup:

1) wood - pine wood