



BOSCH


Compound Mitre Saw

GCM 254 | 3 601 M52 000

Table of Content

Spare parts list.....	2
-----------------------	---

МАГАЗИН
БАШ МАЙСТОРА
ПРОФЕСИОНАЛНИ РЕШЕНИЯ



Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
22	1 619 PB9 048	Pad	1		3	11
23	1 619 PB9 049	Bolt	1		1	10
26	1 619 PB9 052	Base	1		1	39
27	1 619 PB9 053	Label	1		2	10
28	1 619 PB6 151	Spring	1		2	10
29	1 619 PB9 055	Detent	1		1	11
30	1 619 PB9 056	Screw	1		4	10
31	1 619 PB9 057	Spring Clip	1		1	11
32	1 619 PB6 149	Hex Nut Q235A	1		3	10
36	1 619 PB9 062	Scale	1		1	10
37	1 619 PB8 622	Screw	1		7	10
38	1 619 PB9 064	Pointer	1		1	10
39	1 619 PB9 065	Holder	1		1	11
40	1 619 PB9 066	Plate	1		1	11
41	1 619 PB9 067	Arm	1		1	30
42	1 619 PB9 068	Washer	1		2	10
43	1 619 PB9 069	Nut	1		1	11
44	1 619 PB9 070	Rotary Handle	1		1	12
45	1 619 PB6 164	Plain Washer Q235A	1		1	10
46	1 619 PB9 072	Screw	1		1	10
47	1 619 PB9 073	Bolt	1		1	10
48	1 619 PB6 210	Nut	1		4	10
49	1 600 A02 S76	Detent Pin	1		1	12
50	1 619 PB6 174	O-Ring ABS	1		1	10
51	1 619 PB9 077	Laser	1		1	20
52	1 619 PB6 135	Pan head screw YL102	1		1	10
53	1 619 PC0 545	Washer 8X2	1		2	10
54	1 619 PB6 178	Hex Nut Q235A	1		1	10
55	1 619 PB9 081	Pointer	1		1	10
56	1 619 PB9 082	Cover Plate	1		1	11
57	1 619 PB6 152	Bolt YL102	1		1	10
58	1 619 PB9 084	Rotary Handle	1		1	13
59	1 619 PB9 085	Bolt	1		1	11
60	1 619 PB9 086	Mitre Fence	1		1	33
61	1 619 PB9 087	Washer	1		1	10

Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
62	1 619 PB9 088	Mitre Fence	1		1	22
63	1 619 PB9 089	Washer	1		1	11
64	1 619 PB9 090	Nut	1		1	10
65	1 619 PB6 140	Socket head cap screw YL102	1		4	10
66	1 619 PB6 141	Rotary Knob Q235A	1		1	11
67	1 619 PB6 136	Pad	1		1	11
68	1 619 PB9 094	Stopper	1		1	23
145	1 619 PB9 171	Bolt	1		1	10
146	1 619 PB9 172	Bolt	1		2	10
147	1 619 PB6 137	Socket head cap screw PP-GF25+Q235A	1		1	10
156	1 619 PB9 121	Washer	1		1	10
157	1 619 PB6 138	Spring Washer 65MN	1		1	10
159	1 619 PC0 674	Label	1		1	11
654	1 619 PB9 102	Mounting Clamp	1		1	25
655	1 619 PB9 050	Supporting Block	1		1	22
656	1 619 PC0 491	Extension Stand	1		1	26
833	1 619 PB9 145	Table	1		1	38
2	1 619 PB9 033	Field	2		1	36
8	1 619 PB9 080	Nameplate	2		1	13
13	1 619 PB9 042	Ball Bearing	2		1	15
20	1 600 A02 S1Y	Warning Label	2		1	11
84	1 619 PB6 194	Push-Button	2		1	10
85	1 619 PB6 186	Countersunk-Head Screw	2		5	10
86	1 619 PB9 112	Plate	2		1	10
87	1 619 PB9 113	Torsion Spring	2		1	17
88	1 619 PB6 162	Bushing Q235A	2		2	10
89	1 619 PB6 163	Shaft PA6-GF30	2		1	12
91	1 619 PB9 117	Dust Separator	2		1	13
92	1 619 PB9 118	Plate	2		1	22
94	1 619 PB9 120	Bolt	2		1	10
95	1 619 PB6 195	Spring	2		1	11
96	1 619 PB9 122	shaft lock	2		1	12
97	1 619 PB9 123	Rubber Bushing	2		1	12
98	1 619 PB9 124	Baffle	2		1	13

Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
99	1 619 PB9 125	Screw	2		2	10
100	1 619 PB9 126	Cover	2		2	17
101	1 619 PB6 201	Set screw	2		2	10
102	1 619 PB6 202	Pan head screw	2		4	10
103	1 619 PB9 129	Housing Cover	2		1	12
113	1 619 PB6 215	Bolt	2		1	11
114	1 619 PB9 140	Clamping Flange	2		1	16
116	1 619 PB9 115	Clamping Flange	2		1	16
117	1 619 PB9 143	Bolt	2		3	10
127	1 619 PB9 153	Screw	2		3	10
158	1 619 PC0 568	Screw	2		4	10
653	1 619 PB6 246	Dust Bag	2		1	15
801	1 619 PB9 154	Housing Assembly	2		1	29
803	1 619 PB9 155	Armature assembly	2		1	40
810	1 619 PB9 144	Carbon Brush	2		1	25
851	1 619 PB9 156	Drive shaft set	2		1	32
893	1 619 PB9 148	Upper guard	2		1	38
4	1 619 PC0 675	Switch	3		1	25
5	1 619 PB9 046	Power supply cord	3		1	22
6	1 619 PB6 112	Grommet	3		1	11
7	1 619 PB9 038	Cable Clip	3		1	10
12	1 619 PB9 041	Capacitor	3		1	11
19	1 619 PB9 035	Pan head screw	3		10	11
70	1 619 PC0 569	Screw	3		2	10
104	1 619 PB9 130	Linkage	3		1	18
105	1 619 PB6 206	Pan head screw	3		1	10
106	1 619 PB6 204	Shoulder Screw	3		2	10
107	1 619 PB9 133	Plate	3		1	12
109	1 619 PB6 213	Torx Flat-Head Screw	3		2	10
110	1 619 PB6 212	Compression Spring	3		1	10
111	1 619 PB6 214	Cover Plate	3		1	12
112	1 619 PB9 127	Washer	3		1	10
128	1 619 PB6 229	Electronic Module	3		1	20
129	1 619 PB6 232	Terminal Block	3		1	11
130	1 619 PB6 231	Linkage	3		1	10

Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
131	1 619 PB6 243	Linkage	3		1	10
132	1 619 PB9 158	Handle	3		1	17
133	1 619 PB6 235	Pan head screw	3		2	10
134	1 619 PB6 236	Pan head screw	3		2	10
135	1 619 PB6 237	Handle	3		1	14
136	1 619 PB6 239	Switch	3		1	13
137	1 619 PB9 163	Screw	3		1	10
138	1 619 PB6 244	Spring	3		1	10
139	1 619 PB9 165	Induction Coil	3		1	15
140	1 619 PB9 166	Switch Button	3		1	11
141	1 619 PB6 241	Spring	3		1	10
142	1 619 PB9 168	Handle	3		1	17
143	1 619 PB6 228	Interlock	3		1	10
150	1 619 PB9 176	Connecting Cable	3		1	12
151	1 619 PB9 177	Connector Cable	3		1	11
152	1 619 PB6 233	Pan head screw	3		1	10
651	1 619 PB9 159	Clamping wrench	3		1	11
652	1 619 PB9 141	measuring ruler	3		1	10
818	1 619 PB9 151	Plate	3		1	27

